























# Руководство по установке




## Инструменты



## Комплектующие




# Схема сборки




(3)


1



2




3




(4)

4




5




(5)


6



7




8




(6)


9




10



11




12




(7)


13




14



15



16



S-799V

(8)